

ASSEMBLY AND INSTALLATION INSTRUCTIONS

FOR YOUR SAFETY WARNING: BE SURE THE ELECTRICITY TO THE WIRES YOU ARE WORKING ON IS SHUT OFF; EITHER THE FUSE IS REMOVED OR THE CIRCUIT BREAKER IS SHUT OFF. GENERAL You don't need special tools to install this fixture. Be sure to follow the steps in the order given. Under no circumstances should a fixture be hung on house electrical wires, nor should a swag type fixture be installed on a ceiling which contains a radiant type heating system. Read instructions carefully. If you are unclear as to how to proceed, consult a qualified electrician. **NOTE: Proper wiring is essential for the safe operation of this fixture.**

Assembly and Installation Step:

TOOLS REQUIRE:

- Phillips (Star) Screwdriver
- Small hex key (3mm and 4mm)
- Adjustable wrench

1. Anchor bolt set installation :
 - a. Dig a 15" deep hole, 15" diameter where you wish your lantern to be installed.
 - b. Set the 3 Anchor Bolts into the 3 holes of the Mounting bolt template and feed the Electric Wire through the center of the Mounting bolt template.
 - c. Pour concrete into the hole up to the level of the ground and sink the anchor set into the concrete. Make sure the top surface of the Mounting bolt template is level to the ground surface, and the Anchor Bolts protrude above the Mounting bolt template surface by 4-1/8".

NOTE: Make sure the concrete is solid and dry before installing the lamppost. (Usually this takes up to 24 hours.)

2. Attach the Base (2) to the Anchor Bolts, and fasten with the 3 Washers and the 3 Cap Nuts.
3. Attach the Connector to the Base (1), and fasten with 3 Set Screw.
4. Attach the Connector Cover to the Connector, and fasten with the Set Screw.
5. Set the entire post and lantern assembly on to the Base (2), and secure the lamppost using the 3 Washers and the 3 Cap Nuts.

